

DATOS PARA ARRANQUE CON AUTOTRANSFORMADOR 220 VOLTIOS TRIFASICOS

POTENCIA		CONSUMO			BREAKER	FUSIBLES	CONTACTORES G.E.			CONTACTORES C.S.C.			RELETER.	RELETER.
HP	KW	(A)	(A)	(A)		RED	Arr.	Y	RED	Arr.	Y	G.E.	C.S.C.	
3	2,2	9,6	20	32		CL01(12A)	CL00	CL00	C1-D18	C1-D09	C1-D09	RT1N(8-12)	R2-D1314(7-10)	
5	3,7	15,2	32	50		CL02(18A)	CL01	CL00	C1-D25	C1-D18	C1-D09	RT1P(10-16)	R2-D1321(12-18)	
7,5	5,5	21	40	63		CL25(25A)	CL02	CL00	C1-D32	C1-D25	C1-D09	RT1T(17,5-22)	R2-D1322(17-25)	
10	7,5	28	50	63		CL04(32A)	CL02	CL00	C1-D40	C1-D32	C1-D12	RT1V(25-32)	R2-D3353(23-32)G	
15	11	42	100	125		CL06(50A)	CL04	CL01	C1-D65	C1-D40	C1-D18	RT2E(30-43)	R2-D3357(37-50)	
20	15	54	100	125		CL07(65A)	CL45	CL02	C1-D80	C1-D50	C1-D25	RT2G(45-55)	R2-D3359(48-65)	
25	18,5	68	125	125		CL08(80A)	CL06	CL02	C1-F115	C1-D65	C1-D25	RT2J(64-82)	R2-D3361(55-70)	
30	22	80	150	200		CL09(95A)	CL06	CL25	C1-F150	C1-D80	C1-D32	RT2J(64-82)	R2-D3363(63-80)	
40	30	104	200	250		CL10(105A)	CL08	CL04	C1-F185	C1-F115	C1-D40	RT2M(90-110)	LR1-F105(75-105)	
50	37	130	250	315		CK75(150A)	CL09	CL06	C1-F225	C1-F150	C1-D50	RT3E(110-140)	LR1-F160(100-160)	
60	45	154	300	350		CK08(185A)	CL10	CL06	C1-F265	C1-F185	C1-D65	RT3F(14-190)	LR1-F160(100-160)	
75	55	182	350	400		CK08(185A)	CK75	CL06	C1-F330	C1-F185	C1-D80	RT4P(175-280)	LR1-F200(125-200)	
100	75	248	500	600		CK09(250A)	CK08	CL07	C1-F400	C1-F265	C1-D95	RT4P(175-280)	LR1-F250(160-250)	

DATOS PARA ARRANQUE CON AUTOTRANSFORMADOR 440 VOLTIOS TRIFASICOS

POTENCIA		CONSUMO			BREAKER	FUSIBLES	CONTACTORES G.E.			CONTACTORES C.S.C.			RELETER.	RELETER.
HP	KW	(A)	(A)	(A)		RED	Arr.	Y	RED	DELTA	Y	G.E.	C.S.C.	
3	2,2	4,8	10	16		CL00(9A)	CL00	CL00	C1-D09	C1-D09	C1-D09	RT1L(4-6,3)	R2-D1310(4-6)	
5	3,7	7,6	16	16		CL00(9A)	CL00	CL00	C1-D12	C1-D09	C1-D09	RT1M(5,5-8,5)	R2-D1312(5,5-8)	
7,5	5,5	11	25	32		CL01(12A)	CL00	CL00	C1-D18	C1-D12	C1-D09	RT1N(8-12)	R2-D1316(9-13)	
10	7,5	14	30	50		CL02(18A)	CL00	CL00	C1-D25	C1-D18	C1-D09	RT1P(10-16)	R2-D1321(12-18)	
15	11	21	50	63		CL25(25A)	CL02	CL00	C1-D32	C1-D25	C1-D09	RT1T(17,5-22)	R2-D1322(17-25)	
20	15	27	50	63		CL04(32A)	CL02	CL00	C1-D40	C1-D32	C1-D12	RT1V(25-32)	R2-D3353(23-32)G	
25	18,5	34	63	80		CL45(40A)	CL25	CL00	C1-D50	C1-D32	C1-D12	RT1W(30-40)	R2-D3355(30-40)	
30	22	40	75	100		CL06(50A)	CL04	CL01	C1-D65	C1-D40	C1-D18	RT2E(30-43)	R2-D3357(37-50)	
40	30	52	100	125		CL07(65A)	CL45	CL02	C1-D80	C1-D50	C1-D25	RT2G(45-55)	R2-D3359(48-65)	
50	37	65	125	125		CL08(80A)	CL06	CL02	C1-F115	C1-D65	C1-D25	RT2J(64-82)	R2-D3361(55-70)	
60	45	77	150	160		CL08(80A)	CL06	CL25	C1-F115	C1-D80	C1-D32	RT2J(64-82)	R2-D3363(63-80)	
75	55	96	200	250		CL10(105A)	CL07	CL25	C1-F150	C1-D95	C1-D40	RT2L(78-97)	LR1-F105(75-105)	
100	75	124	250	315		CK75(150A)	CL08	CL04	C1-F225	C1-F150	C1-D50	RT3E(110-140)	LR1-F125(95-125)	

