

POTENCIA		CONSUMO	BREAKER	FUSIBLES	CONTACTOR	CONTACTOR	RELE TER.	RELE TER.
HP	KW	(A)	(A)	(A)	G.E. EUROPA-INDIA	C.S.C.	G.E. EUROPA-INDIA	C.S.C.
1/4	0.18	2.9	6	6	CL00/CB4 (9 A)	C1 - D09	RT1K/CBR1 4.0 (2,5 - 4)	R2-D1308 (2,5 - 4)
1/2	0.37	4.8	10	6	CL00/CB4 (9 A)	C1 - D09	RT1L/CBR1 6.0 (4 - 6,3)	R2-D1310 (6 - 6)
1	0.75	8	16	10	CL01/CB5 (12 A)	C1 - D12	RT1M/CBR1 8.0 (5,5 - 8,5)	R2-D1314 (7 - 10)
1,5	1.1	10	20	16	CL01/CB5 (12 A)	C1 - D18	RT1N/CBR1 13.0 (8 - 12)	R2-D1316 (9 - 13)
2	1.5	12	25	20	CL02/CB7 (18 A)	C1 - D18	RT1P/CBR1 18.0 (10 - 16)	R2-D1316 (9 - 13)
3	2.2	17	40	20	CL25/CB11 (25 A)	C1 - D25	RT1S/CBR1 18.0 (14,5 - 17,5)	R2-D1321 (12 - 18)
5	3.7	28	50	32	CL04/CB15 (32 A)	C1 - D40	RT1V/CBR2 32.0 (25 - 32)	R2-D3353 (23 - 32) GDE.
7,5	5.5	40	70	50	CL06/CB22 (50 A)	C1 - D65	RT2E/CBR3 50.0 (30 - 43)	R2-D3357 (37 - 50)
10	7.5	50	100	63	CL07/CB30 (65 A)	C1 - D80	RT2G/CBR3 65.0 (42 - 55)	R2-D3359 (48 - 65)